



## Premium Sponge Rubber Weatherstrip

### Easy to Use:

1. Apply to clean, dry surface at temperatures above 40°F (5°C). Expose adhesive by peeling off backing paper 6" to 8" at a time.

2. Press in place and trim to length.

**Door:** Apply to door jamb so tape is compressed between jamb and edge of closing door.

**Window:** Place tape on bottom of sash rail to form seal when window is closed.

Use on auto doors, trunks, sunroofs, marine hatches and more

